

efergy

REDUCE
MONITOR
SAVE

TECHNICAL INFORMATION

Voltage	230 V AC / 50 Hz
Rating	230V AC / 2900W max
Learning code	1 million
Remote Frequency	433.92MHz
Remote Range	20 Meters
ON/OFF Indicate	LED
Battery Type	L1028* 1-12V DC Alkaline

CE RoHS    N16354

REMOTE CONTROLLED SOCKETS
ENERGY SAVING ADAPTOR

efergy

REDUCE
MONITOR
SAVE



INSTRUCTION MANUAL

SAVE ENERGY

The efergy remote controlled socket allows you to turn your appliances on and off remotely. It saves you time, effort, TVs, microwave or lamps. The remote controlled socket is great for hard to reach sockets under desk or behind TVs or microwaves. Attach a trailing socket to turn off several appliances at once.

SET UP

- Your pack contains 3-5 sockets (receivers) and 1 remote control
- Insert the batteries provided into the remote control
- Plug 1 of the sockets into a mains power outlet, the LED light will flash
- Select and press one of the ON switches on the remote control
- The LED light will then flash continuously then stop. The socket is now paired to this ON switch on the remote
- You can now remotely control the socket and any appliance connected
- Repeat this process for the other sockets selecting a different ON button on the remote for each different socket

NOTE – when there is a power blackout or the socket is removed from the mains, you will need to repeat the set up process to the sockets and the remote.

USING THE REMOTE

- Plug the appliance you want to operate remotely into the socket
- Press the corresponding ON button that is paired to this socket for 2 seconds. The appliance will turn on.
- Use the corresponding OFF button to turn the appliance off remotely

TROUBLE SHOOTING

- If the socket does not respond to the remote control please check the following:
 - The battery may be low, check the battery and replace if necessary.
 - The distance between the remote and the socket may be too great. Move the remote closer to the socket.
 - Ensure you are pressing the ON button and the remote for 1-2 seconds.

HOW TO DECODE

- Press the ON/OFF button on the socket and hold for 3 seconds.
- The LED light will flash quickly then stop. Decoding is successful.
- Alternatively, press and hold the OFF button on the remote control for 3 seconds. The LED light will flash quickly then stop. Decoding is successful.